

# HI STRIKER CO.

## 573-265-2100

### Rules for Operation of Dunk Tank

1. **NEVER** operate Dunk Tank around electricity.
2. **ADULTS ONLY** to operate and supervise Dunk Tank.
3. Water level in tank should be kept at least 6" from top of tank.
4. Participants must be at least 5' tall.
5. Only one person allowed on seat or in the tank.
6. Check that seat is secured prior to placing full weight on seat.
7. When tank is not in operation or unattended, always drain the water.
8. **NEVER** stand on the seat.
9. Caution should be taken that participant sit up straight; keep hands on lap; keep legs together.
10. **NEVER** allow participant to hold on to bars or stick feet through bars.
11. Operator only permitted behind tank or target area.
12. Persons who have used drugs or alcohol are **NOT** permitted in tank.
13. Maximum weight limit is 250 pounds.